

# DAEWOO EVANDA

USE CABLE C11, TAKE OFF CAREFULLY NAILS, AND REMOVE ALL PLASTICS TILL WE HAVE CLEAN THE BOARD, NOW SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

