

FERRARI 599 GTB FIORANO



USE CABLE C4, OPEN BACK COVER FROM DASH, CAREFULLY, THEN LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

