

FIAT BRAVO-BRAVA-MAREA @28



USE CABLE C11, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, REMOVE CAREFULLY NAILS, ALL THAT WE NEED TILL WE HAVE CLEAN BOARD, AND DISCONNECT SMALL BOARD FROM BIG PART, THEN SOLDER CABLE LEADS ACORDING TO COLOURS AS SHOWN OF PHOTO BELOW IN BOTH SIDES:

