## FIAT MULTIPLA TO 2002

Use cable C4, open rear part of dash, then some screws that appears, nails and you will have free the main board, then locate eprom memory 93C56, and clip it checking pin 1 as shown of below photo:



