FIAT PANDA FROM 2006



Use cable ${\it C4}$, take off dash from car dash, open all dash, please make it carefully. When we have main board on our hands locate eprom memory, and clip it checking pin 1 as shown of photo below:

