
FIAT UNO BASIC



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EPROM MEMORY 95040, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

