FORD C-MAX 95320



Use cable C4, open dash, please make it carefully, then locate eprom memory 95320, and clip it checking Pin 1 as shown on photo below:

