

# FORD F150 2009



USE CABLE C12, ON THE BACK SIDE OF DASH, CAREFULLY CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON THE BELOW PHOTO:

