

# FORD FUSSION 9s12



USE CABLE C12, REMOVE BACK PLASTIC COVER, LOOK FOR POINTS ON MAIN BOARD AND SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON PHOTO BELOW:

