

FORD SCORPIO



USE CABLE C11, REMOVE BACK COVER FROM DASH, LOCATE HC11 MICRO AND SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON PHOTO BELOW:

