FORD TOURNEO 9512



USE CABLE C12, OPEN BACK SIDE OF DASH, CAREFULLY, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN OF BELOW PHOTO:

