

HONDA CBR 600F FROM 2001



USE CABLE C4, REMOVE BACK COVER, CAREFULLY, THEN LOCATE 93C56 MEMORY EEPROM, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

