

HONDA PANTHEON



USE CABLE C7, OPEN BACK DASH COVER, THEN LOCATE POINTS ON THE MAIN BOARD, AND THEN SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER-COLOUR:

