

# HONDA ST1300 PAN EUROPEAN



USE C7 CABLE, REMOVE BACK PLASTIC COVER FROM DASH, AND THEN LOCATE POINTS IN THE MAIN BOARD LIKE ON PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

