

HONDA VTR 1000 FIRESTORM



USE C7 CABLE, OPEN DASH AND REMOVE SPEEDOMETER LIKE WE CAN SHOW ON PHOTOS, THEN SOLDER CABLE LEADS ACCORDING TO COLOUR:

