

HYUNDAI ATOS



USE CABLE C4, REMOVE BACK PLASTIC COVER, CAREFULLY, THEN LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

