

HYUNDAI MATRIX FROM 2010



Use CABLE C4, OPEN BACK COVER FROM DASH, CAREFULLY, THEN LOCATE EEPROM MEMORY AND CLIP IT CHECKING **PIN 1** AS SHOWN ON BELOW PHOTO:

