## JAGUAR S-TYPE FROM 2006



USE CABLE C12 O HCS12, REMOVE BACK COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON PHOTO:

