

KTM 93c56



USE CABLE C4, REMOVE OUTSIDE PLASTIC COVERS FROM DASH, CAREFULLY, AND THEN ON THE BACK OF MAIN BOARD LOCATE EEPROM MEMORY AND CLIP IT CHECKING **PIN 1** AS WE CAN SEE ON THIS PHOTO BELOW:

