

LAMBORGHINI DIABLO



USE CABLE C4, OPEN DASH CAREFULLY WITHOUT NEED TO TOUCH NAIL, NOW LOCATE EPROM, AND CLIP IT CHECKING PIN 1 AS SHOWN ON THE PHOTO BELOW:

