LANCIA Y FROM 2005



Use cable C4, open all dash, but we must take MUCH carefully, we must take off nails, then locate eprom 93C66 memory, and clip it checking pin 1 as shown of below photo:

