## MAZDA 626 FROM2001



USE CABLE C4, OPEN ALL DASH COMPLETLY, CAREFULLY, THEN LOCATE EPROM MEMORY, AND CLIP IT CHECKING PIN 1 AS SHOWN ON BELOW PHOTO:

