

# MERCEDES BENZ A-W168 DASH



THIS VEHICLE CAN BE MODIFIED BY OBD BUT IN CASE WE WANT TO DO IT DIRECT, WE HAVE TO USE CABLE C12, REMOVE BACK PLASTIC COVER FROM DASH, THEN CONNECT OR SOLDER CABLE LEADS ACCORDING TO COLOURS AS SHOWN ON BELOW PHOTOS:

