MERCEDESBENZ E-W211 EZS HC12 FROM 2002

USE CABLE C45 + A6 ADAPTER. REMOVE MODULE FROM CAR CAREFULLY:



NOW REMOVE BACK PLASTIC COVER FROM EZS, AND LOCATE POINTS ON THE BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

