

MICROCAR



USE CABLE C4, OPEN ALL DASH, PLEASE MAKE IT CAREFULLY, THEN LOCATE EPROM MEMORY, AND CLIP IT CHECKING **PIN 1** AS SHOWN ON BELOW PHOTO:

