

# mitsubishi legacy 93c46



USE C7 CABLE, OPEN DASH AND REMOVE SPEEDOMETER ONLY, IT IS THE SCREEN ONE, THEN WE CAN SEE THE 93C46 EPROM, WE HAVE TO LOCATE POINTS ON THE BOARD, AND SOLDER CABLE LEADS ACCORDING WITH ITS NUMBERS-COLOUR:

