MITSUBISHI MONTERO SPORT



USE C7 CABLE, OPEN DASH AND REMOVE SPEDOMETER:



Now only solder cable leads according to points as shown on below photo:

