

# OPEL CORSA D FROM 2006



USE CABLE C4, OPEN ALL DASH, CAREFULLY, REMOVE NEEDLES AND SCREEN, WITH MAIN BOARD ON OUR HANDS, LOCATE EPROM MEMORY M35080, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW, SOMETIMES EPROM NEED TO BE REPLACED:

