OPEL MOVANO 2002



Use cable C4, open all dash, please make it carefully, then locate eprom memory 95020, usually we don't need to desolder it, and clip it checking pin 1 as shown of photo below:

