

# PEUGEOT 106



USE SPECIFIC CABLE C21, TAKE OFF DASH FROM CAR, CONNECT PLUG TO DASH LIKE WE CAN SEE ON NEXT PHOTO AND RUN PROGRAM:

