

PEUGEOT 4007



USE C7 CABLE, WE ONLY NEED TO REMOVE BACK PLASTIC COVER FROM DASH, AND THEN LOCATE POINTS IN THE MAIN BOARD LIKE WE CAN SEE ON THE BELOW PHOTO AND SOLDER CABLE LEADS AS IT SHOWS TO US:

