

PEUGEOT 406 BSI TO 2002



USE CABLE C4, TAKE OFF BACK SIDE FROM BSI, AND LOCATE EEPROM MEMORY 93C66 AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

