

PEUGEOT 406 DASH SAGEM TO 2000



USE CABLE **C4**, OPEN ALL DASH, THEN REMOVE ALL PLASTIC INSIDE WITH NAILS AND ENGINES, MAKE ALL WORK WITH BIG CAREFULL, THEN LOCATE EPROM **93C46**, CLIP IT CHECKING **PIN 1** AS SHOWN ON PHOTO BELOW:

