PEUGEOT 807 DASH WITH NAVI



USE CABLE C4, REMOVE BACK PLASTIC COVER FROM DASH, PLEASE MAKE IT CAREFULLY, DON'T NEED TO TOUCH NAILS, THEN LOCATE EEPROM 25020 EPROM AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

