PEUGEOT PARTNER DASH 2008



USE CABLE C4, OPEN DASH COMPLETLY, PLEASE MAKE IT CAREFULLY, NAILS HAVE A LITTLE DIFICULTY, BUT... WHEN WE HAVE ALL BOARD FREE IN OUR HANDS, LOCATE EEPROM 95020, SOMETIMES MUST BE DESOLDER, AND CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

