

RENAULT AVANTIME DASH



USE CABLE C12, REMOVE DASH FROM CAR AND REMOVE UPPER PLASTIC COVER CAREFULLY. WHEN WE CAN SEE MAIN BOARD, SOLDER CABLE LEADS ACCORDING TO COLOURS AS YOU CAN SEE ON PHOTO BELOW:

