RENAULT TWINGO FROM 2007



Use cable **C4**, open all dash, please make it carefully when touch screen, then locate eprom memory **93C56**, we don't need to desolder it, and clip it checking pin 1 as shown of photo below:

