

# SAAB 95 S130



USE CABLE C4, REMOVE REAR PLASTIC COVER. THEN LOCATE EPROM MEMORY 93C46 OR S130, SOMETIMES THIS MUST BE DESOLDER TO SHOW NEW VALUE ON DISPLAY, CLIP IT CHECKING PIN 1 AS SHOWN OF PHOTO BELOW:

