## SMART FORTWO 999 SAM SECURED



USE CABLE C45 + A6 ADAPTER, OPEN SAM COMPLETLY. NOW LOCATE POINTS ON THE BOARD LIKE ON BELOW PHOTO AND SOLDER CABLE LEADS AS IT SHOWS TO US:

