SSANGYONG ACTYON



USE CABLE **C4**, OPEN DASH COMPLETLY, CAREFULLY, WHEN WE HAVE MAIN BOARDS IN OUR HANDS WE MUST LOCATE EPROM, AND CLIP IT CHECKING **PIN 1** AS SHOWN OF BELOW PHOTO:

