SSANGYONG KYRON



Use cable C4, open dash completly, carefully, when we have main boards in our hands we must locate eprom, and clip it checking pin1 as shown of below photo:

