

## SUBARU FORESTER C46



Use C4 CABLE, TAKE OFF ONLY SPEDOMETER, IT IS THE SCREEN ONE, THEN WE CAN SEE THE 93C46 EPROM, AND WITH THE PHOTO BELOW WE CAN CLIP MEMORY OR WE CAN CHOOSE TO MAKE BY BACK SOLDERING CABLE FOR IT C7:

