

# SUZUKI JIMMY C46



Use C7 CABLE, OPEN  
DASH AND REMOVE  
SPEEDOMETER:



NOW ONLY SOLDER CABLE LEADS ACCORDING TO POINTS AS SHOWN ON BELOW  
PHOTO:

