

# TOYOTA TUNDRA 93C66



USE CABLE C4, REMOVE BACK PLASTIC COVER, CAREFULLY, THEN LOCATE EPROM, AND CLIP IT CHECKING PIN 1 AS BELOW PHOTO SHOW TO US:

