Volvo 540-V40 To 2003



Use cable C4, open carefully all dash, we don't need to desolder anything, speedo engine then locate eprom 93C56 memory, and clip it checking pin 1 as shown of below photo:

