

VOLVO XC90



USE C12 CABLE, REMOVE DASH FROM CAR AND OPEN IT COMPLETELY. LOCATE POINTS IN THE MAIN BOARD LIKE IN PHOTO BELOW AND SOLDER CABLE LEADS AS IT SHOWS TO US:

