

# VW CADDY To 2003



Use CABLE C5, REMOVE BACK PLASTIC COVER FROM DASH USING TORX SCREW, PLEASE MAKE IT CAREFULLY, THEN LOCATE EEPROM 93C46 MEMORY AND CLIP IT CHECKING PIN1 AS SHOWN OF PHOTO BELOW:

