

VW CONSTELLATION BCU



USE CABLE C4, REMOVE OUTSIDE COVER FROM BCU, THEN LOCATE EEPROM AND CLIP IT CHECKING **PIN 1** AS SHOWN OF PHOTO BELOW:

