

VOLKSWAGEN GOLF 6 MAGNETI MARELLI



USE CABLE C12, REMOVE DASH'S BACK PLASTIC COVER, PLEASE MAKE IT CAREFULLY, THEN SOLDER CABLE LEADS ACCORDING TO COLOURS AS PHOTO BELOW SHOWS TO US:

