

YAMAHA R1 To 2003



USE CABLE C7, OPEN BACK DASH COVER, THEN LOCATE POINTS ON THE MAIN BOARD, AND THEN SOLDER CABLE LEADS CONCORDANCE WITH ITS NUMBER-COLOUR:

